



# NEED HELP? - USER GUIDE

Scan code for more info

GILMAN HALL

For **HELP** during academic classes, Mon.- Fri. 8am - 8pm

# call 410-516-6699


For all other events, support is only available if scheduled in advance by calling 410-516-8303

For all Facilities related needs, please contact Plant Operations at 6-8063 or submit a work request at <http://www.fm.jhu.edu>

## 1. TURN THE SYSTEM ON

Press the **POWER ON** button or select an input to power up the system and turn on the projector.

The button will flash while the projector is warming up. The button will remain steadily lit when the projector is ready to use.



## 2. SELECT AN INPUT

Press the source button of the input you wish to use : **Blu Ray** (may also have a VCR), **Floor Box** or **MAC Laptop**, **Doc Cam** or **Aux Video**.

## 3. USE EQUIPMENT

For laptops the optimum resolution is **1280x800** .

For more in depth instruction on using the system scan the QR code above or head to <http://www.jhu.edu/classrooms>

**MUTE**— Use to mute the projector for times when you do not wish to project your source.

**HELP**— During regular support hours, please call 410-516-6699 if you need additional assistance.

## 4. TURN THE SYSTEM OFF

When you are finished, please press the **POWER OFF** button to turn off the system and projector. The button will flash while the projector is powering down. You will not be able to turn the projector back on during this cycle.

Be sure that you have ejected any media you may have used and take with you your laptop/accessories.

The technology in this room is supported by Academic Technology Facilities. We welcome your ideas. Please contact us at [www.jhu.edu/classrooms/feedback.html](http://www.jhu.edu/classrooms/feedback.html)